

1. Dial the combination wheels to 0-0-0-0 and withdraw the cable.
2. Turn the knob (B) 90 degrees clockwise to the designated position.
3. Reset the combination wheels to the desired combination, making sure the numbers are lined up with the pointer (A).
4. Having selected your combination numbers, turn the knob (B) back to the original position in a counterclockwise direction

